



FITTING INSTRUCTIONS FOR FP0097 FORK PROTECTORS
DUCATI MULTISTRADA 1200 2010




THIS KIT CONTAINS THE ITEMS PICTURED AND LABELLED BELOW.
DO NOT PROCEED UNTIL YOU ARE SURE ALL PARTS ARE PRESENT.

Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike

Please note that in cases where kits are packed with a plastic tube separating components on the spindle bar (this tube should be discarded).

THE PARTS SHOWN MAY BE REPRESENTATIVE ONLY (FOR CLARITY OF INSTRUCTIONS ONLY)





TOOLS REQUIRED

- Socket set to include 2x 13 sockets and wrenches

FITTING INSTRUCTIONS

- Pass spindle bar through front wheel spindle with equal amounts protruding from either side.
- Fit the smaller spacer on left hand side so the smaller spigot fits into spindle.
- On right hand side fit the larger spacer over spindle bar so larger spigot sits into spindle.
- Fit bobbins to either end of spindle bar so the bobbins fit over spigots on both spacers.
- Fit washers and nuts from kit onto both threaded ends of spindle bar and tighten until both nuts are engaged in nylon and equal amounts protrude from either side. Do not overtighten – the nyloc nuts will hold it tight.

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in resellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.

R&G Racing

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ

Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



FRANCE
INSTRUCTIONS DE MONTAGE DE LA PROTECTION
FP0097
DUCATI MULTISTRADA 1200 2010

THIS KIT CONTAINS THE ITEMS PICTURED AND LABELLED BELOW.
DO NOT PROCEED UNTIL YOU ARE SURE ALL PARTS ARE PRESENT.

Merci de noter que les pièces assemblées dans l'emballage ne sont pas nécessairement dans le sens du montage à réaliser sur la moto. Enlever le tube en plastique transparent si celui-ci est présenté dans l'emballage.

OUTILS NECESSAIRES

- 2 Clés de 13 mm à douilles

MONTAGE

- Passer la barre R&G à travers l'axe de roue avant.
- Glisser l'entretoise la plus petite sur l'axe R&G sur le côté gauche de la moto. (le côté le plus petit à l'intérieur de la fourche).
- Glisser l'entretoise la plus grande sur l'axe R&G sur le côté droit de la moto. (le côté le plus large à l'intérieur de la fourche).
- Placer les tampons de chaque côté de la fourche.
- Glisser ensuite une rondelle sur chaque coté de l'axe contre les tampons.
- Visser ensuite un écrou de chaque côté de l'axe.
- Serrer les deux écrous. **Ne pas serrer trop fortement, en effet les écrous autobloquants garderont le montage en place.**