



Fitting Instructions for RAD0076BK/TI Radiator Guard Aprilia RSV4 '09

**In This Kit There Should Be
1x Radiator Guard
8x Cable/Zip Ties
2x 100mm Lengths of Foam**

- To fit the radiator guard to the bike cut the foam strip provided into 10mm wide pieces and stick them to the back of the radiator guard frame, so that they sit between the radiator guard and the radiator. Use 4 of the cable ties, 2 at the top and 2 at the bottom. The top two go through the slots at the top of the guard and around the mounting brackets of the radiator. At the bottom pass the cable ties through the bottom of the radiator matrix and then through the slots at the bottom of the guard. When the guard is in position tighten all of the cable ties.

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.



FRANCE
Instructions de montage de RAD0076BK/TI
Aprilia RSV4 '09

Ce kit contient
1x Protection de radiateur
8 x Colliers de serrage
2x bandes de mousse

- Pour fixer la protection de radiateur sur la moto, vous devez couper des morceaux de mousse de 10 mm et les coller sur l'arrière de l'armature de la protection (de manière à ce qu'ils soient positionnés entre le radiateur et la protection R&G). Utiliser les colliers de serrage pour maintenir la protection sur la moto. Deux colliers devront passer à travers les passants de la protection et entoureront les pattes de maintien du radiateur supérieures sur la moto.
Pour la fixation du bas, utiliser les autres colliers de serrage et passer les colliers à travers les fixations de la protection puis les passer à travers le radiateur.
Serre le tout une fois la protection correctement mise en place.

Montageanleitung für den RAD0076BK/TI Kühlerschutz
Aprilia RSV4 '09

Dieser Kit enthält:
1x Kühlerschutz
8x Kabelbinder
2x 100mm Schaumstoffstreifen

- Um den Kühlerschutz am Motorrad zu montieren, schneiden Sie zuerst die mitgelieferten Schaumstoffstreifen in 10 mm breiten Streifen und kleben Sie diese auf der Rückseite des Kühlerschutzrahmens, so dass sie zwischen dem Kühlerschutz und dem Kühler angebracht sind. Verwenden Sie 4 Kabelbinder (2 unten und 2 oben). Oben: Führen Sie die zwei Kabelbinder durch die zwei Schlitze oben auf dem Kühlerschutz, dann um die oberen Kühlerschutzhalter. Unten: Führen Sie die Kabelbinder durch das Kühlergitter, dann durch die Schlitze unten auf dem Kühlerschutz. Wenn der Kühlerschutz in der richtigen Position ist, ziehen Sie alle Kabelbinder fest.