



Fitting Instructions for RAD0142BK Radiator Guard
TRIUMPH STREET TRIPLE 2013



In This Kit There Should Be
1x Radiator Guard (RAD0142BK)
2x 100mm Lengths of self-adhesive Foam



Picture 1



Picture 2



Picture 3

TOOLS REQUIRED

- Socket set to include 8 & 10mm socket & wrench.

FITTING INSTRUCTIONS

- To fit the radiator guard to the bike cut the foam strip provided into 10mm wide pieces and stick them to the back of the radiator guard frame, so that they sit between the radiator guard and the radiator.
- Remove the nut on the top left and bolt on the top right of the radiator that mounts it to the frame, as shown in picture 1.
- Remove the bolt that mounts the bottom of the radiator, as shown in picture 2.
- Offer the R&G Radiator Guard into position and locate the upper tab on the left side over the exposed thread, before loosely refitting the original nut.
- On the other side of the bike, refit the original bolt through the upper tab on the radiator guard, before inserting through the radiator mount and loosely tighten into the frame mount.
- On the bottom of the radiator guard, refit the original bolt through the radiator guard, then the radiator mount and loosely tighten into the threaded boss on the mounting bracket, as shown in picture 3.
- Tighten all bolts evenly and ensure the radiator is correctly mounted.

ISSUE 1 18/12/2012 (AR)

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.

R&G Racing

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ

Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



Instructions de montage pour RAD0142BK Protection radiateur
TRIUMPH STREET TRIPLE 2013



Le kit doit contenir :
1x Protection radiateur (RAD0142BK).
2x 100mm Longueur de mousse autocollante



Photo 1



Photo 2



Photo 3

Outils requis

- Clé à molette 8 & 10mm

Instructions de montage :

- Couper la mousse en bandeaux de 10mm puis collez ces bandeaux au bas du support de protection radiateur, de façon à ce que ces bandeaux se situent entre la protection radiateur et le radiateur.
- Enlever l'écrou en haut à gauche ainsi que le boulon en haut à droite du radiateur, qui le fixent au cadre (Photo 1).
- Enlever le boulon qui fixe le bas du radiateur (Photo 2).
- Mettre la protection radiateur R&G en position puis and loger la languette supérieure du côté gauche autour du filetage, avant de remettre l'écrou d'origine.
- De l'autre côté de la moto, remettre le boulon d'origine à travers la languette supérieure sur la protection radiateur, avant de l'insérer à travers le support radiateur et serrer légèrement dans le support cadre.
- Au bas de la protection radiateur, remettre le boulon d'origine à travers la protection radiateur, puis le support radiateur puis serrer légèrement dans le patron fileté dans le support de fixation (Photo 3).
- Serrer tous les boulons de façon égale et assurez vous que le radiateur soit correctement monté.

ISSUE 1 18/12/2012 (AR)



Montageanleitung für den RAD0142BK Kühlerschutz
TRIUMPH STREET TRIPLE 2013



Dieser Kit beinhaltet:
1x Kühlerschutz (RAD0142BK)
2x 100mm selbstklebende Schaumstoffstreifen



Abbildung 1



Abbildung 2



Abbildung 3

SIE BENÖTIGEN FOLGENDES WERKZEUG:

- 8 & 10mm Steckschlüssel

MONTAGEANLEITUNG

- Um den Kühlerschutz am Motorrad zu montieren, schneiden Sie zuerst die mitgelieferten Schaumstoffstreifen in 10 mm breiten Streifen und kleben Sie diese auf der Rückseite des Kühlerschutzrahmens, so dass sie zwischen dem Kühlerschutz und dem Kühler angebracht sind.
- Entfernen Sie die Mutter oben links und die Schraube oben rechts am Kühler, die den Kühler am Rahmen befestigen – siehe Abbildung 1.
- Entfernen Sie die Schraube, die den Kühler unten befestigt – siehe Abbildung 2.
- Den R&G Kühlerschutz in Position bringen und die obere Lasche auf der linken Seite über dem hervorstehenden Gewinde anbringen, dann mit der Originalschraube fixieren (noch nicht fest ziehen).
- Auf der anderen Seite des Motorrads, die Originalschraube durch die obere Lasche des Kühlerschutzes in die Kühlerhalterung einführen und anschließend an der Rahmenhalterung fixieren (noch nicht festziehen).
- Montieren Sie die Originalschraube wieder durch den Kühlerschutz (am Kühlerschutz unten), dann durch die Kühlerhalterung und an der Lochplatte auf der Montagehalterung fixieren (siehe Abbildung 3).
- Ziehen Sie alle Schrauben fest und überprüfen Sie, dass der Kühler ordnungsgemäß montiert ist.

AUSGABE 1 18/12/2012 (AR)