

## **24444** BMW F900R & F900XR Shock Shield Fitting Instructions

### Kit Includes:

1X	C24444	Rubber Flap
1X	CFK24444	Bracket
2X	CBOLM50002	M5 X 10mm Stainless Bolt
1X	CBOLM60007	M6 X 12mm Stainless Bolt
2X	CNUTM50002	M5 Stainless Nyloc Nut
2X	CWASM50001	M5 Washer

- The Pyramid Shock Shield is simple to fit. Attach the rubber flap to the Bracket using the **M5 X 10mm Stainless Bolts, M5 Stainless Nyloc Nuts & M5 Washers**.
- Remove the nut cap and nut from the side of the alternator regulator (**see Fig 1**). Refit the nut and nut cap with the Pyramid Shock Shield incorporated.
- On the left-hand side of the bike, use the **M6 X 12mm Stainless Bolt** to attach the other end of the Pyramid Shock Shield (**see Fig 2**).
- Check fixings periodically.

### Any questions?

[sales@pyramid-plastics.co.uk](mailto:sales@pyramid-plastics.co.uk)

+44 (0)1427 677990

[www.pyramid-plastics.co.uk](http://www.pyramid-plastics.co.uk)



Follow us on social media and feel free to leave us a review!

