

PYRAMID



816001M Triumph Tiger 800 Shock Shield Instructions

Kit Includes:

1X	Shock Shield Moulding	C816001M
1X	Chain-guard Extension Moulding	C816001M
1X	Stick-Fit Pads	CTAP0052
2X	Adhesive Grip Tape	CSAN0002
1X	Alcohol Wipe	CWIP002

Chain-guard Extension supplied fits from 2010 to 2014 only.

NOTE: For best results make sure room temperature is at least 12 degrees or above

- Key surface of Shock Shield with sandpaper provided.
- Key surface of Chain-guard Extension and Chain-guard if required.
- Clean all Surfaces with warm soapy water and dry.
- Wipe surfaces with alcohol wipe provided.
- Apply the stick-fit pads to areas of contact (pictured below) on both the Shock Shield and Chain-guard. There is no need to overload the product with the stick fit pads. Use enough to cover the areas shown below.
- Use a clamp to secure chain-guard in place and using a large piece of fabric or something to that effect force it into the area between the rear wheel and Shock Shield firmly securing it in place.
- Leave to set for a minimum of 24 hours, please DO NOT be tempted to "test" the adhesion.



Stick-fit application is recommended in these 'cross-hatched' areas.



Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk

Follow us on social media and feel free to leave us a review!

