



FITTING INSTRUCTIONS FOR PKS0021 KICKSTAND SHOE
BMW F800 GT '13-



Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike.

THE PARTS SHOWN MAY BE REPRESENTATIVE ONLY (FOR CLARITY OF INSTRUCTIONS ONLY)

Please note that in cases where kits are packed with rubber washers holding the components onto the bolt – *the rubber washers should be thrown away!*



BASE PLATE

CLAMP PLATE AND BOLTS

TOOLS REQUIRED

- 3mm A/F Allen key.

FITTING INSTRUCTIONS

- Place the clamp plate (pictured above right) over the side stand base and position up the side stand shaft with the counter-sinks upper-most.
- Take the aluminium machined base plate (picture above left) and fit to the base of the side stand from underneath so it is aligned with the clamp plate.
- Use the three counter-sunk bolts to secure in position, ensuring the inside edge of the clamp plate clamps down on the top of the side stand base
- Tighten all bolts evenly and check to ensure the side stand pad clears the chain when in the raised position.



- If fitting to older stands that have been worn the padding strip should be placed in the base plate to ensure a tighter fit.

ISSUE 1 01/05/2013 (NSY)

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and d



Instructions de montage PKS0021 Support de béquille
BMW F800 GT 2013



LA FAÇON DONT LE KIT EST EMBALLE NE CORRESPOND PAS FORCEMENT A LA FAÇON DE MONTER LES PIECES SUR LA MOTO.

Les pièces présentées peuvent N'ÊTRE QUE REPRESENTATIVES (afin de faciliter et clarifier les instructions de montage).

NOTEZ QUE SI LES KITS SONT EMBALLÉS AVEC DES RONDELLES EN CAOUTCHOUC SERVANT À TENIR LES COMPOSANTS, CES RONDELLES DOIVENT ÊTRE JETÉES.



BASE PLATE

ATTACHE PLATE ET BOULONS

Outils requis

- Clé Allen 3mm

Instructions de montage:

- Placer l'attache plate (Photo en haut à droite) autour de la base de la béquille et positionner l'arbre à béquille latérale dessus.
- Prendre la base plate usinée (Photo en haut à gauche) et placez-la à la base de la béquille par dessous de manière à ce qu'elle soit alignée avec la plaque de serrage.
- Utiliser les 3 boulons plats pour fixer la position, en vous assurant que le bord intérieur de la plaque serre sur la partie supérieure de la béquille latérale de base.
- Serrer tous les boulons de façon égale et assurez-vous que le support de béquille soit espacé de la chaîne lorsqu'elle est dans la position relevée.

ISSUE 1 01/05/2013 (nsy)

R&G Racing
Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ
Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com